

RENISHAW 

**MP1 probe with
inductive or hard wired
transmission system**

1997 Renishaw. All rights reserved.

Renishaw® is a registered trademark of Renishaw plc.

This document may not be copied or reproduced in whole or in part, or transferred to any other media or language, by any means without the written prior permission of Renishaw.

The publication of material within this document does not imply freedom from the patent rights of Renishaw plc.

Disclaimer

Considerable effort has been made to ensure that the contents of this document are free from inaccuracies and omissions. However, Renishaw makes no warranties with respect to the contents of this document and specifically disclaims any implied warranties. Renishaw reserves the right to make changes to this document and to the product described herein without obligation to notify any person of such changes.

Renishaw part no: H-2000-5001-01-D

Issued: August 2001

Installation and User's Guide
MP1 inspection probe
with inductive or
hard wired transmission system



FCC DECLARATION (USA)**FCC Section 15.19**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC Section 15.105

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference, in which case you will be required to correct the interference at your own expense.

FCC Section 15.21

The user is cautioned that any changes or modifications not expressly approved by Renishaw plc, or authorised representative could void the user's authority to operate the equipment.

FCC Section 15.27

The user is also cautioned that any peripheral device installed with this equipment such as a computer, must be connected with a high-quality shielded cable to insure compliance with FCC limits.

**GB
SAFETY****Information for the user**

Beware of unexpected movement. The user should remain outside of the full working envelope of Probe Head/Extension/Probe combinations.

In all applications involving the use of Machine Tools or CMMs, eye protection is recommended.

Remove power before performing any maintenance operations.

Refer to the machine supplier's operating instructions.

Information for the machine supplier

It is the machine supplier's responsibility to ensure that the user is made aware of any hazards involved in operation, including those mentioned in Renishaw product documentation, and to ensure that adequate guards and safety interlocks are provided.

Under certain circumstances the probe signal may falsely indicate a probe seated condition. Do not rely on probe signals to stop machine movement.

D**SICHERHEITSANWEISUNGEN****Informationen für den Benutzer**

Auf unerwartete Bewegungen achten. Der Anwender soll sich immer außerhalb des Meßtasterkopf-Arm-Meßtaster-Bereichs aufhalten.

Bei der Bedienung von Werkzeugmaschinen oder Koordinatenmeßanlagen ist Augenschutz empfohlen.

Bevor Wartungsarbeiten begonnen werden, muß erst die Stromversorgung getrennt werden.

Beziehen Sie sich auf die Wartungsanleitungen des Lieferanten.

Informationen für den Maschinenlieferanten

Es obliegt dem Maschinenlieferanten, den Anwender über alle Gefahren, die sich aus dem Betrieb der Ausrüstung, einschließlich der, die in der Renishaw Produktdokumentation erwähnt sind, zu unterrichten und zu versichern, daß ausreichende Sicherheitsvorrichtungen und Verriegelungen eingebaut sind.

Unter gewissen Umständen könnte das Meßtaster-signal fälschlicherweise melden, daß der Meßtaster nicht ausgelenkt ist. Verlassen Sie sich nicht allein auf Sondersignale, um sich über Maschinenbewegungen zu informieren.

DK**SIKKERHED****Oplysninger til brugeren**

Pas på uventede bevægelser. Brugeren bør holde sig uden for hele sondehovedets/forlængerens/sondens arbejdsområde.

I alle tilfælde, hvor der anvendes værktøjs- og koordinatmålemaskiner, anbefales det at bære øjenbeskyttelse.

Afbryd strømforsyningen, før der foretages vedligeholdelse.

Se maskinleverandørens brugervejledning.

Oplysninger til maskinleverandøren

Det er maskinleverandørens ansvar at sikre, at brugeren er bekendt med eventuelle risici i forbindelse med driften, herunder de risici, som er nævnt i Renishaws produktdokumentation, og at sikre, at der er tilstrækkelig afskærmning og sikkerhedsblokeringer.

Under visse omstændigheder kan sondesignalet ved en fejl angive, at sonden står stille. Stol ikke på, at sondesignaler stopper maskinens bevægelse.

E

SEGURIDAD**Información para el usuario**

Tener cuidado con los movimientos inesperados. El usuario debe quedarse fuera del grupo operativo completo compuesto por la cabeza de sonda/ extensión/sonda o cualquier combinación de las mismas.

Se recomienda usar protección para los ojos en todas las aplicaciones que implican el uso de máquinas herramientas y máquinas de medición de coordenadas.

Quitar la corriente antes de emprender cualquier operación de mantenimiento.

Remitirse a las instrucciones de manejo del proveedor de la máquina.

Información para el proveedor de la máquina

Corresponde al proveedor de la máquina asegurar que el usuario esté consciente de cualquier peligro que implica el manejo de la máquina, incluyendo los que se mencionan en la documentación sobre los productos Renishaw y le corresponde también asegurarse de proporcionar dispositivos de protección y dispositivos de bloqueo de seguridad adecuados.

Bajo determinadas circunstancias la señal de la sonda puede indicar erróneamente que la sonda está asentada. No fiarse de las señales de la sonda para parar el movimiento de la máquina.

F

SECURITE**Informations à l'attention de l'utilisateur**

Attention aux mouvements brusques. L'utilisateur doit toujours rester en dehors de la zone de sécurité des installations multiples Tête de Palpeur/Rallonge/ Palpeur.

Le port de lunettes de protection est recommandé pour toute application sur machine-outil et MMC.

Mettre la machine hors tension avant d'entreprendre toute opération de maintenance.

Consulter le mode d'emploi du fournisseur de la machine.

Informations à l'attention du fournisseur de la machine

Il incombe au fournisseur de la machine d'assurer que l'utilisateur prenne connaissance des dangers d'exploitation, y compris ceux décrits dans la documentation du produit Renishaw, et d'assurer que des protections et verrouillages de sûreté adéquats soient prévus.

Dans certains cas, il est possible que le signal du palpeur indique à tort l'état que le palpeur est au repos. Ne pas se fier aux signaux du palpeur qui ne garantissent pas toujours l'arrêt de la machine.

FIN

TURVALLISUUTTA**Käyttäjälle tarkoitettuja tietoja**

Varo äkillistä liikettä. Käyttäjän tulee pysytellä täysin anturin pään/jatkeen/anturin yhdistelmää suojaavan toimivan kotelon ulkopuolella.

Kaikkia työstökoneita ja koordinoituja mittauskoneita (CMM) käytettäessä suositamme silmäsuojuksia.

Kytke pois sähköverkosta ennen huoltotoimenpiteitä.

Katso koneen toimittajalle tarkoitettuja käyttöohjeita.

Tietoja koneen toimittajalle

Koneen toimittaja on velvollinen selittämään käyttäjälle mahdolliset käyttöön liittyvät vaarat, mukaan lukien Renishaw'n tuoteselosteessa mainitut vaarat. Toimittajan tulee myös varmistaa, että toimitus sisältää riittävän määrän suoja- ja lukkoja.

Tietuissa olosuhteissa anturimerkki saattaa osoittaa virheellisesti, että kyseessä on anturiin liittyvä ongelma. Älä luota anturimerkkeihin koneen liikkeen pysäyttämiseksi.

GR

ΑΣΦΑΛΕΙΑ**Πληροφορίες για τους χρήστες**

Προσοχή - κίνδυνος απροσδόκητων κινήσεων. Οι χρήστες πρέπει να παραμένουν εκτός του χώρου που επηρεάζεται από όλους τους συνδυασμούς λειτουργίας της κεφαλής του ανιχνευτή, της προέκτασης και του ανιχνευτή.

Σε όλες τις εφαρμογές που συνεπάγονται τη χρήση εργαλείων μηχανημάτων και εξαρτημάτων CMM, συνιστάται η χρήση συσκευής προστασίας των ματιών.

Αποσυνδέστε το μηχάνημα από το ηλεκτρικό ρεύμα προτού επιχειρήσετε τυχόν εργασίες συντήρησης.

Βλέπετε τις οδηγίες λειτουργίας του προμηθευτή του μηχανήματος.

Πληροφορίες για τους προμηθευτές των μηχανημάτων

Αποτελεί ευθύνη του προμηθευτή του μηχανήματος να εξασφαλίσει ότι ο χρήστης είναι ενήμερος τυχόν κινδύνων που συνεπάγεται η λειτουργία, συμπεριλαμβανομένων και όσων αναφέρονται στο διαφωτιστικό υλικό του προϊόντος της Renishaw. Είναι επίσης ευθύνη του να εξασφαλίσει ότι υπάρχουν τα απαιτούμενα προστατευτικά καλύμματα καλύμματα και συνδέσεις ασφάλειας.

Υπό ορισμένες συνθήκες μπορεί το σήμα ανιχνευτή να δώσει εσφαλμένη ένδειξη θέσης του ανιχνευτή. Μη βασίζεστε στα σήματα ανιχνευτή για θέση της κίνησης του μηχανήματος εκτός λειτουργίας.

I

SICUREZZA**Informazioni per l'utente**

Fare attenzione ai movimenti inaspettati.

Si raccomanda all'utente di tenersi al di fuori dell'involucro operativo della testina della sonda, prolunghe e altre varianti della sonda.

Si raccomanda di indossare occhiali di protezione in applicazioni che comportano macchine utensili e macchine per misurare a coordinate.

Prima di effettuare qualsiasi intervento di manutenzione, isolare dall'alimentazione di rete.

Consultare le istruzioni d'uso del fabbricante della macchina.

Informazioni per il fabbricante della macchina

Il fornitore della macchina ha la responsabilità di avvertire l'utente dei pericoli inerenti al funzionamento della stessa, compresi quelli riportati nelle istruzioni della Renishaw, e di mettere a disposizione i ripari di sicurezza e gli interruttori di esclusione.

E' possibile, in certe situazioni, che la sonda emetta erroneamente un segnale che la sonda è in posizione. Evitare di fare affidamento sugli impulsi trasmessi dalla sonda per arrestare la macchina.

NL

VEILIGHEID**Informatie voor de Gebruiker**

Oppassen voor onverwachte beweging. De gebruiker dient buiten het werkende signaalveld van de Sondekop/Extensie/Sonde combinaties te blijven.

Het dragen van oogbescherming wordt tijdens gebruik van Machinewerktuigen en CMM's aanbevolen.

Voordat u enig onderhoud verricht dient u de stroom uit te schakelen.

De bedieningsinstructies van de machineleverancier raadplegen.

Informatie voor de Machineleverancier

De leverancier van de machine is ervoorverantwoordelijk dat de gebruiker op de hoogte wordt gesteld van de risico's die verbonden zijn aan bediening, waaronder de risico's die vermeld worden in de produktendocumentatie van Renishaw.

De leverancier dient er tevens voor te zorgen dat de gebruiker is voorzien van voldoende beveiligingen en veiligheidsrendelinrichtingen.

Onder bepaalde omstandigheden kan het sondesignaal een onjuiste sondetoestand aangeven. Vertrouw niet op de sondesignalen voor het stoppen van de machinebeweging.

P**SEGURANÇA****Informações para o Utilizador**

Tomar cuidado com movimento inesperado. O utilizador deve permanecer fora do perímetro da área de trabalho das combinações Cabeça da Sonda/Extensão/Sonda.

Em todas as aplicações que envolvam a utilização de Máquinas-Ferramenta e CMMs, recomenda-se usar protecção para os olhos.

Desligar a alimentação antes de efectuar qualquer operação de manutenção.

Consultar as instruções de funcionamento do fornecedor da máquina.

Informações para o Fornecedor da Máquina

É responsabilidade do fornecedor da máquina as segurar que o utilizador é consciencializado de quaisquer perigos envolvidos na operação, incluindo os mencionados na documentação do produto Renishaw e assegurar que são fornecidos resguardos e interbloqueios de segurança adequados.

Em certas circunstâncias, o sinal da sonda pode indicar falsamente uma condição de sonda assentada. Não confiar em sinais da sonda para parar o movimento da máquina.

SW**SÅKERHET****Information för användaren**

Se upp för plötsliga rörelser. Användaren bör befinna sig utanför arbetsområdet för sondhuvudet/förlängningen/sond-kombinationerna.

Ögonskydd rekommenderas för alla tillämpningar som involverar bruket av maskinverktyg och CMM.

Koppla bort strömmen innan underhåll utförs.

Se maskintillverkarens bruksanvisning.

Information för maskinleverantören

Maskinleverantören ansvarar för att användaren informeras om de risker som drift innebär, inklusive de som nämns i Renishaws produktokumentation, samt att tillräckligt goda skydd och säkerhetsförelagningar tillhandahålls.

Under vissa omständigheter kan sondens signal falskt ange att en sond är monterad. Lita ej på sondersignaler för att stoppa maskinens rörelse.

Installation and Users Guide - English

WARRANTY

Equipment requiring attention under warranty must be returned to your supplier. No claims will be considered where Renishaw equipment has been misused, or repairs or adjustments have been attempted by unauthorised persons.

CHANGES TO EQUIPMENT

Renishaw reserves the right to change specifications without notice.

CNC MACHINE

CNC machine tools must always be operated by competent persons in accordance with manufacturers instructions.

CARE OF THE PROBE

Treat the probe as a precision instrument.

IP RATING IPX8.

ENVIRONMENT

Temperature

The MP1 probe is specified for storage over -10° to 70°C (14 to 158°F) and operation over 0° to 60°C (32° to 140°F) ambient temperature range.

PATENT NOTICE

Features of Renishaw products are the subject of one or more of the following patents and patent applications:

DE	3234241	US	4542467
GB	2108715	US	4636960
JP	1,847,335		

Contents

INSTALLATION				MAINTENANCE	1-14
Typical probe system - inductive ...		1-2		Diaphragm inspection	1-14
Typical probe system - hard Wired		1-3		FAULT FINDING	1-16
MP1 probe types		1-4		SCREW TORQUE VALUES ...	1-18
MP1 specification		1-5		APPENDIX 1 Inductive transmission	1-19
MP1 general arrangement ...		1-6		APPENDIX 2 Adaptors and extensions	1-20
MP1-S with IMP assembly ...		1-7		APPENDIX 3 3 way mounting block	1-21
Stylus spring pressure adjustment		1-8		APPENDIX 4 MI 5 interface ...	1-22
Stylus on-centre adjustment ...		1-9		APPENDIX 5 MI 8 interface ...	1-22
OPERATION				APPENDIX 6 MI 8-4 interface ...	1-23
Probe moves		1-10		APPENDIX 7 PSU3 power supply	1-23
Software requirements		1-11		APPENDIX 8 Stylus weak link ...	1-24
Typical probe cycles		1-12		PARTS LIST	1-25


TYPICAL PROBE SYSTEM - Inductive transmission

MACHINING CENTRE JOB SET-UP and INSPECTION Inductive signal transmission

1. Workpiece.
2. Machine spindle.
3. Shank.
4. MP1-S probe
5. Stylus.
7. Inductive module probe (IMP).
8. Inductive module machine (IMM).
9. Cable.
10. MI 5 interface unit.
12. CNC machine control.
14. PSU3 power supply unit.
optional.

TOOL SETTING Hard wired signal transmission


4. LP2 probe.
6. Square tip stylus.
9. Cable.
11. MI 5, MI 8 or MI 8-4 interface.
12. CNC machine control.
14. PSU3 power supply unit.
optional.
15. Socket for LP2.



TYPICAL PROBE SYSTEM - Hard wired transmission

**MACHINING CENTRE
JOB SET-UP and INSPECTION**
Hard wired signal transmission

1. 3 way mounting block.
2. Cover (shorting socket).
3. MP1-R probe.
4. Stylus.
5. Wires.
6. Interface unit.
MI 5, MI 8 or MI 8-4.
7. CNC machine control.
8. PSU3 power supply unit.
optional.



There are two versions of the MP1 Probe.


1. The **MP1-S** with side electrical connection for inductive signal transmission systems. Inductive transmission allows automatic tool change of the probe as any other tool in the the system.

The IMP assembly is attached to the probe using the screws supplied with the assembly.

Tighten the screws in accordance with the screw torque values given on page 1-18.

2. The **MP1-R** with rear electrical connection for hard wired signal transmission systems, typically vertical turning lathes.

MP1 PROBE TYPES



MP1 SPECIFICATION

REPEATABILITY

A rigid probe mounting is essential for good repeatability.

Max 2 sigma (2 σ) value


Repeatability of 1,0 μ m (40 μ in) is valid for test velocity of 480mm/min (1.57ft/min) at the stylus tip using a stylus 50mm (1.97in) long.

STYLUS TRIGGER FORCE


Set at factory using stylus 50mm (1.97in) long.
X and Y trigger forces vary around the stylus seating.

X -Y direction 0,57 - 1,15N
 57 - 115gf
 (2.01-4.05ozf)

Z direction 3,8N
 380gf
 (13.40ozf)





MP1 GENERAL ARRANGEMENT - dimensions mm (in)




Mounting

Four holes - tap M4 x 0.7 - 12 full depth thread equi-spaced on 52.5 (2.07) PCD



MP1-S probe




MP1-R probe

MP1-S with IMP ARM - dimensions mm (in)



Renishaw provide a comprehensive range of IMP's and IMM's. The range is listed in Data Sheet ITS Part No. H-2000-2140.

Dimension **K** is available in increments of 5mm, from 40 to 120mm (1.57 to 4.72in).

Dimension **J** is available in increments of 5mm, from 20 to 80mm (0.78 to 3.15in).



Shank
Renishaw supply probe ready shanks. Details available on application.



STYLUS SPRING PRESSURE ADJUSTMENT - gauging force

Spring pressure within the probe causes the stylus to sit in one unique position, and return to this position following each stylus deflection.

Spring pressure is set by Renishaw. The user should only adjust spring pressure in special circumstances e.g. excessive machine vibration or insufficient pressure to support the stylus weight. The probe is removed from its mounting to gain access to the spring pressure adjusting screw.

Turn the adjusting screw anti-clockwise to reduce pressure for greater sensitivity or clockwise to increase pressure.


MP1 base seal

When the probe head is separated from its mounting, the seal will become ineffective.

The probe base must be cleaned and a new seal fitted prior to re-assembly.

The seal is supplied with protective paper on the lower and upper surfaces. When the paper is removed the adhesive surface is exposed ready for attachment to the probe and mounting surface.

STYLUS SPRING PRESSURE ADJUSTMENT AND USE OF STYLI OTHER THAN CALIBRATION STYLUS TYPE, MAY CAUSE REPEATABILITY TO DIFFER FROM THE TEST CERTIFICATE RESULTS.



STYLUS ON-CENTRE ADJUSTMENT

Stylus alignment with the spindle centre line need only be approximate, except in the following circumstances.

1. Alignment must be as exact as possible, when probe vector software is used.
2. The probe must be parallel to the spindle axis to prevent stylus stem contact when gauging deep holes.
3. When the machine control software cannot compensate for an offset stylus.

How to check stylus position

Stylus tip and stem position are established using a low force (less than 0,2N / 0,045 lbf.) dial test indicator or setting gauge.


Alternatively rotate the stylus ball against a flat surface. Alignment is good when the stylus ball maintains a consistent distance from the flat surface.

Stylus alignment

To adjust stylus alignment, slacken the probe head holding screws to allow the probe head to pivot on the Ø8mm ball.

Adjust and tighten these four screws to lock the probe head in its new position. Then check the new position for alignment.

When the stylus is correctly aligned, check tightness of holding screws, and replace the front cover.



PROBE MOVES

Probe trigger

A probe trigger signal is generated when the probe stylus is driven against a surface. The machine control records the contact position and instructs machine motion to stop.

High probing speeds are desirable, however a probing velocity must be chosen which allows the machine to stop within the limits of stylus overtravel and machine measuring capability. Follow feed rate guide lines given by supplier.


To ensure a trigger signal is given, drive the probe against the workpiece to a target beyond the expected surface, but within the limits of stylus overtravel.

After the probe stylus touches the surface, reverse clear of the surface.


Single and double touch

With some types of controllers, it is an advantage to use a two touch method as poor repeatability can result at higher feed rates,

If the probe operating sequence is based on a single touch, then the probe may be returned to its start point, following a gauging move.



With a double touch sequence the first move finds the surface quickly. Then the probe is reversed to a position clear of the surface, before making the second touch at a slower feed rate, thereby recording the surface position at a higher resolution.



PROBE MOVES

System delays

System delays are repeatable to less than 2 μ s, and are constant in each direction measurement is taken.

Delays are automatically compensated for, provided a calibration move is made in the same direction and velocity as each measurement move.

Calibrating a system

Calibrate the probe system, at a constant measurement speed in the measurement direction, to automatically compensate for errors - in the following circumstances.

1. Before the system is used.
2. When a new stylus is used.
3. If the stylus is bent.
4. To allow for machine thermal growth.
5. Poor shank relocation repeatability, in the machine spindle.

Probe cycles and features are machine software dependent

Software for probing routines is available from Renishaw

SOFTWARE REQUIREMENTS

SOFTWARE for TURNING and MACHINING CENTRES

Good software will allow the following functions :

- Simple to use calibration routines
- Update a tool offset.
- Generate an alarm if a broken tool is found or set a flag for corrective action.
- Update work co-ordinate systems for positioning.
- Report measured sizes and update tool offsets for automatic tool offset compensations.
- Print data in the form of an inspection report to an external PC / printer.
- Set tolerances on features.

Verify your software

- 1 Does your software have suitable calibration routines which compensate for stylus on centre errors. If not you must set the probe stylus on centre mechanically.

Note - machining centre applications :

When using probe styli which are not on spindle centre, spindle orientation repeatability is important to avoid probe measurement errors.


- 2 Does your software compensate for probe triggering characteristics in all measuring directions.
- 3 Does the software automatically adjust the program co-ordinate system to the relevant set-up feature on the component, for job set-up purposes.

SOFTWARE for MACHINING CENTRES


Simple to use canned cycles for basic features

CALIBRATION


Probe XY offset calibration




Stylus ball radius calibration



Probe length calibration




PROBE COLLISION PROTECTION



TOOL SETTING PROBE

Length setting
(rotating and non rotating)




Diameter setting
(rotating)




Broken tool detection

INSPECTION


Bore and boss measure




Web and pocket measure



Internal and external corner find



XYZ single surface position




Inspection print-out

COMPONENT No. 1				
OFFSET NO.	NOMINAL DIMENSION	TOLERANCE	DEVIATION FROM NOMINAL	COMMENTS
99	1.5000	.1000	.0105	
97	200.0000	.1000	.2054	OUT OF TOL


SOFTWARE for MACHINING CENTRES
Simple to use canned cycles for additional features

INSPECTION


Bore and boss (three point)




Angled web and pocket measure




Angled surface measure




Stock allowance




Bore and boss on PCD



4th axis measure



Feature to feature measure



MAINTENANCE

THE PROBE IS A PRECISION TOOL HANDLE WITH CARE
ENSURE THE PROBE IS FIRMLY SECURED IN ITS MOUNTING

SAFETY - SWITCH POWER OFF WHEN WORKING INSIDE ELECTRICAL COMPONENTS

Although Renishaw probes require little maintenance, the performance of the probe will be adversely affected if dirt, chips or liquids are allowed to enter the sealed working parts.

Therefore keep all components clean and free from grease and oil. Periodically check cables for signs of damage, corrosion or loose connections.


OUTER DIAPHRAGM INSPECTION.

The probe mechanism is protected by two diaphragms, these provide adequate protection under normal working conditions. The user should periodically check the outer diaphragm, for signs of damage and coolant leakage. If this is evident replace the outer diaphragm.

The outer diaphragm is resistant to coolant and oils. However if the outer diaphragm is damaged, the inner diaphragm could become weakened with prolonged immersion in certain coolants and oils.

The user must not remove the inner diaphragm, if damaged, return the probe to your supplier for repair.

WARNING: NEVER ATTEMPT TO REMOVE DIAPHRAGM WITH METAL OBJECTS



DIAPHRAGM INSPECTION

1. Remove the stylus.
2. Unscrew the front cover.
3. Inspect outer diaphragm for damage.
4. To remove outer diaphragm, grip near the middle and pull upwards.

INNER DIAPHRAGM INSPECTION


5. Inspect inner diaphragm for damage.

If damaged return the probe to your supplier for repair.

DO NOT REMOVE INNER DIAPHRAGM

OUTER DIAPHRAGM REPLACEMENT

6. Screw tool fully into stylus holder.
7. Fit new diaphragm.
8. The diaphragm must locate centrally in the stylus holder groove.
9. Press diaphragm to expel trapped air.
10. Remove tool.
11. Lightly lubricate diaphragm rim surface. Then refit front cover.
12. Refit stylus.



FAULT FINDING**COMPLETE FAILURE**

Transmission modules not correctly aligned.	Align correctly.
Transmission modules damaged.	Return to supplier for repair. To check IMM, place metal disc against IMM. The audible indicator should bleep when disc is removed. If it does not bleep, replace IMM.
Swarf blocking inductive transmission air gap.	Clean out.
Loose mounting.	Check all bolted or screwed connections for tightness.
Interface LED does not light up.	Check fuses.
Poor electrical connection.	Check connectors.
Cable screen broken.	Replace cable.
Incorrect voltage.	Check supply.
Probe failure.	No continuity through probe circuit.
Probe spring pressure too low.	Tighten stylus spring pressure.
Probe mounting damaged.	Repair or replace.

**IF THESE CHECKS DO NOT ELIMINATE THE FAULT,
CONSULT YOUR PROBE SUPPLIER.**

FAULT FINDING**POOR REPEATABILITY**

Transmission modules not correctly aligned.	Align correctly.
Loose mounting.	Check all bolts and screwed connections for tightness.
Loose stylus.	Tighten.
Poor electrical connections.	Check connectors.
Excessive machine vibration.	Tighten spring pressure.

SPURIOUS READING

Cable screen broken.	Replace.
Poorly regulated supply voltage.	Regulate correctly.
Excessive machine vibration.	Eliminate vibration or adjust stylus spring pressure.

POOR RE-ARMING


The probe is armed when the stylus mounting is seated, the electrical circuit is complete and the interface LED is lit.

Spring pressure too low.	Adjust spring pressure.
Inner diaphragm pierced or damaged.	Return to supplier for repair.


**IF THE PROBE OR INTERFACE CONTINUES TO MALFUCTION,
RETURN TO YOUR SUPPLIER FOR REPAIR.**

SCREW TORQUE VALUES - Nm (lbf.ft)

HARD WIRED TRANSMISSION



INDUCTIVE TRANSMISSION



APPENDIX 1

INDUCTIVE SIGNAL TRANSMISSION MODULES - MACHINING CENTRE

Inductive transmission systems are fully described in Data Sheet ITS H-2000-2140

IMP installation is fully described in IMP Installation Guide H-2000-4037

IMM installation is fully described in IMM Installation Guide H-2000-4039


SIGNAL TRANSMISSION MODULES

Inductive module probe (IMP)

Inductive module machine (IMM)

Inductive signal transmission modules pass power and signals across an air gap between the IMP and IMM, allowing the probe unit to be easily transferred between the machine spindle and machine tool store, as any other tool in the system.

Modules are always installed in pairs and must locate within specified separation (air gap) and eccentricity limits.



APPENDIX 2 ADAPTORS and EXTENSIONS

Adaptors and extensions are fully described in Data Sheet AEH H-2000-2120

IMP's are fully described in Data Sheet ITS H-2000-2140

ADAPTORS

Features with restricted access can be probed using an LP2 probe.

The MA1 and MA1-R adaptors allow the MP1 probe to be substituted with an LP2 probe.

The MA1 connects directly to the IMP assembly.


The MA1-R connects directly to a 3 way mounting block or equivalent mounting.

EXTENSIONS


Extensions allow deeper access into workpiece features.

LPE extensions with M16 thread, are suitable for machining centre applications using the LP2 probe.

MP1 probe replaced by
MA1-R adaptor + LP2 probe



MP1 probe replaced by
MA1 adaptor + LP2 probe




dimensions mm (in)

APPENDIX 3

3 WAY MOUNTING BLOCK for MP1 PROBES (or LP2 probe with adaptor)

The mounting will accept 1 to 3 probes. A probe or cover must be fitted in each mounting position to complete the electrical circuit.

dimensions mm (in)



Each mounting block is supplied complete with :

- 2 Covers (shorting socket).
- 3 $\text{Ø}8\text{mm}$ balls.
- 2 Dowels.


Mounting blocks are typically used on probing systems for vertical turning lathes or other installations requiring hard wired signal transmission.

APPENDIX 4 MI 5 INTERFACE UNIT

The MI 5 is fully described in
User's Guide H-2000-5014

The MI 5 interface is used with inductive and/or hard wired signal transmission systems. System status is presented visually in a continuously updated form, on the front panel diagnostic LED display, and by outputs available from the MI 5 to the CNC control.

Front View



Probe status LED
(Light emitting diode)

Lit when probe is at rest
or interface is inhibited.

LED off indicates probe stylus
is deflected or power is off.

Audible indicator
A tone is emitted
each time stylus is
deflected or returns
to rest.

INTERFACE UNIT


**Interface units convert probe signals
into an acceptable form for the CNC
machine control.**

APPENDIX 5 MI 8 INTERFACE UNIT

The MI 8 is fully described in
User's Guide H-2000-5015

The MI 8 interface is used with hard wired signal
transmission systems. System status is presented
visually in a continuously updated form on the front
panel diagnostic LED display, and by outputs available
from the MI 8 to the CNC control.

Front View



Probe status LED
(Light emitting diode)

Lit when probe is at rest
or interface is inhibited.

LED off indicates probe stylus
is deflected or power is off.

Switch SW1

Output N/C
(normally closed)

Output N/O
(normally open)


APPENDIX 6

MI 8-4 INTERFACE UNIT

The MI 8-4 is fully described in
User's Guide H-2000-5008

The MI 8-4 is used with hard wired signal transmission systems. it connects to the machine control input, or it connects into the 4 wire Fanuc 'Automatic Length Measurement' input (XAE, ZAE).

Front view



Bi-colour probe status LED
(Light emitting diode)

Green when probe is at rest
or interface is inhibited.

Red when probe stylus is
deflected.

LED off indicates power is off.

Switch SW1

Output high
or
output low

Diagnostic LED's

Indicate direction of
machine movement

APPENDIX 7

PSU3 POWER SUPPLY UNIT

The PSU3 is fully described in
User's Guide H-2000-5057

The PSU3 provides a +24V supply for Renishaw
interface units when a power supply is not
available from the CNC machine control.


Front view



Power LED

(Light emitting diode)
When the green LED is lit,
the power supply is on.

Rear view



Mains switch

On/off

APPENDIX 8


WEAK LINK FOR STYLI WITH STEEL SHAFT - optional

In the event of excessive stylus overtravel the weak link stem is designed to break, thereby protecting the probe from damage.

FITTING STYLUS WITH WEAK LINK ONTO A TYPICAL PROBE

Screw torque value - 2 Nm (1.7 lbf.ft)

Take care to avoid stressing the weak link during assembly




Attach the weak link to the stylus, by rotating the tommy bar and holding the spanner steady.

Fit the stylus with weak link to the probe.

Note:

THE WEAK LINK IS NOT USED WITH CERAMIC SHAFT STYLI

TO REMOVE A BROKEN STEM



To remove broken portion of stem from the stylus, use the spanner and tommy bar.

The broken portion of stem attached to the probe is removed with the spanner.

PARTS LIST - Please quote the Part No. when ordering equipment

Type	Part No.	Description
MP1-S	A-2051-4576	MP1-S probe (side electrical connection) with holding screws & TK1 tool kit.
MP1-R	A-2051-4577	MP1-R probe (rear electrical connection) with holding screws & TK1 tool kit.
ACCESSORIES		
Styli	—	For complete listing - see Renishaw styli guide H-1000-3200.
Stylus	A-5000-3709	Ceramic stylus 50mm long with Ø6mm ball.
Stylus	A-5000-3712	Ceramic stylus 100mm long with Ø6mm ball.
W link kit	A-2085-0068	Weak link kit comprising : Two stylus weak link stems and spanner.
Weak link	M-2085-0069	Stylus weak link stem.
Spanner	P-BT03-0001	Spanner for stylus weak link stem.
Screw	P-SC01-0430	Cap head screw M4 x 0,7 - 30mm long, probe holding screws - 4 required.
TK1 kit	A-2053-7531	TK1 - Probe head tool kit comprising :
DK1 kit	A-2051-7105	Stylus tool, 1,5mm, 2,0mm, 2,5mm 3,0mm and 4,0mm hexagon keys. DK1 - MP1 outer diaphragm replacement kit.
Seal	M-2051-4522	Base seal for MP1-S.
Seal	M-2054-6583	Base seal for MP1-R.
Ø8 ball	P-BA03-0800	Ø8mm Ball (pivot for stylus on-centre adjustment).
Plug	P-CN07-2002	5 way DIN plug for MP1-R mounting block (connects to interface cable).
Shank	—	Renishaw supply probe ready shanks - details available on application.
MOUNTING BLOCK		
Mtg block	A-2051-4777	3 way mounting block complete with 2 covers (shorting socket).
Cover	A-1016-6363	Cover (shorting socket) for 3 way mounting block.
EXTENSIONS and ADAPTOR		
MA1	A-2051-7080	MA1 adaptor - allows LP2 probe to be used in place of MP1-S probe.
MA1-R	A-2051-7146	MA1-R adaptor - allows LP2 probe to be used in place of MP1-R probe.
LPE1	A-2063-7001	LPE1 extension bar Ø25 x 50mm long.
LPE2	A-2063-7002	LPE2 extension bar Ø25 x 100mm long.
LPE3	A-2063-7003	LPE3 extension bar Ø25 x 150mm long.
SOFTWARE		
Software	—	Probe software for machine tools - see Data Sheet H-2000-2289.

Australia – Renishaw Oceania Pty Ltd

Tel +61 3 9553 8267
Fax +61 3 9592 6738
email australia@renishaw.com

Brazil – Renishaw Latino

Americana Ltda
Tel +55 11 4195 2866
Fax +55 11 4195 1641
email brazil@renishaw.com

The People's Republic of China –

Renishaw Representative Office
Tel +86 10 6410 7993
Fax +86 10 6410 7992
email china@renishaw.com

France – Renishaw S.A.

Tel +33 1 64 61 84 84
Fax +33 1 64 61 65 26
email france@renishaw.com

Germany – Renishaw GmbH

Tel +49 7127 9810
Fax +49 7127 88237
email germany@renishaw.com

Hong Kong – Renishaw (Hong Kong)

Ltd
Tel +852 2753 0638
Fax +852 2756 8786
email hongkong@renishaw.com

India – Renishaw Metrology Systems
Private Ltd

Tel +91 80 5320 144
Fax +91 80 5320 140
email india@renishaw.com

Indonesia – Renishaw Representative

Office
Tel +62 21 428 70153
Fax +62 21 424 3934
email indonesia@renishaw.com

Italy – Renishaw S.p.A.

Tel +39 011 966 10 52
Fax +39 011 966 40 83
email italy@renishaw.com

Japan – Renishaw K.K.

Tel +81 3 5332 6021
Fax +81 3 5332 6025
email japan@renishaw.com

The Netherlands – Renishaw

International BV
Tel +31 76 543 11 00
Fax +31 76 543 11 09
email benelux@renishaw.com

Singapore – Renishaw Representative

Office
Tel +65 897 5466
Fax +65 897 5467
email singapore@renishaw.com

Slovenia – RLS merilna tehnika d.o.o.

Tel +386 1 52 72 100
Fax +386 1 52 72 129
email mail@rls.si

South Korea – Renishaw Liaison

Office
Tel +82 2 565 6878
Fax +82 2 565 6879
email southkorea@renishaw.com

Spain – Renishaw Iberica S.A.

Tel +34 93 478 21 31
Fax +34 93 478 16 08
email spain@renishaw.com

Switzerland – Renishaw A.G.

Tel +41 55 415 50 60
Fax +41 55 415 50 69
email switzerland@renishaw.com

Taiwan – Renishaw Representative

Office
Tel +886 4 251 3665
Fax +886 4 251 3621
email taiwan@renishaw.com

UK (Head Office) – Renishaw plc

Tel +44 1453 524524
Fax +44 1453 524901
email uk@renishaw.com

USA – Renishaw Inc

Tel +1 847 286 9953
Fax +1 847 286 9974
email usa@renishaw.com

For all other countries

Tel +44 1453 524524
Fax +44 1453 524901
email international@renishaw.com

RENISHAW 

www.renishaw.com